

## Instructions HOFEN XL

The installation must be done by a qualified electrician who follows these instructions scrupulously. Only qualified personnel should perform maintenance operations on the product. Ensure the rated voltage of the device is compatible with the power supply voltage. Use a supply cable in conformity with the requirements of the low voltage installations standards. The product should not be altered. Any alteration can make the product hazardous and voids the guarantee.

### I. Specifications

Power	15W
Power sourcing	220-240Vac
Class	II
IP	44
Colour temperature	3000K   4200K   6500K
Lumen	1200lm
Installation	Encastrar teto
Application	Interior



### WARNING!



Not suitable for covering with thermally insulating material.

**TAKE NOTICE:** LED react sensitive on high temperatures! Before installation pay attention to the expected temperature at the place of operation. This may not exceed the allowed ambient temperature ( $t_a=25^{\circ}\text{C}$ ) of the product.

IP44 RoHS

## II. Installation

1

- Switch off the power.
- Drill the hole in the ceiling in compliance with the Led spot.

2

- Connect the power cable to the Fast Connector.
- We recommend the use of fast connectors LIG F252, cod.1890660005.

3

- Install the spot in the hole.
- Switch on the power.