

HYDRA LED INSTRUCTIONS

1. Switch off

1
2. Remove the cover
3. Mount the base on the ceiling with screws

2
4. Wire the cables

3
5. Replace the cover back on the base

4



All responsibilities for defects or damages are hereby rejected if caused by: incorrect assembling of the product, incorrect supply, use of lamps not suitable for this product, external agents.